# Honeywell

# **BLUETOOTH SPEAKER**

Owner's manual

Please read the manual carefully before use



#### Secure Connection Limited

Flat H. 11th Floor, Tower 6, Grand Water Front, 38 San Ma Tau Street, To Kwa Wan, KL, Hong Kong Customer Care Email: supportishoneywellconnection.com TeL: +852 5803 1828 Web: www.honeywellconnection.com The Honeywell trademark is used under license from Honeywell International Inc. Honeywell International Inc. makes no representations or warranties with respect to this product is manufactured by Secure Connection Limited. Hong Kong.

All trade names are registered trademarks of respective manufacturers listed. ©2024 Secure Connection Limited, Hong Kong. All rights reserved.

Honeywell

HC000118/AUD/BTS/U300/BLK HC000119/AUD/BTS/U300/BLU

www.honeywellconnection.com info@honeywellconnection.com

#### Dear Customer.

Thank you for purchasing Honeywell Trueno U300 Bluetooth Speaker. In order to facilitate the installation and use of this Multifunctional Bluetooth Speaker, we recommend that you carefully read this manual, and keep it stored safely. To ensure that you always enjoy quality sound, please use this manual for proper use and maintenance of your product.

If any questions arise during use, please consult this manual. If it is in accordance with the warranty, we kindly welcome you to contact us at:

#### support@honeywellconnection.com

We welcome any comments or suggestions you may have about our products and service.

# Contents

1.	What's in the Box	0.
2.	Performance Index	0.
3.	Product Appearance and Structure	02
4.	Function Description	02
5.	How to Operate	0.
5.1.	Charging	0.
5.2.	Powering on	0.
5.3.	Pairing via Bluetooth	0.
5.4.	MicroSD Card Operation	04
5.5.	AUX Cable Operation	04
5.6.	USB Function	04
5.7.	Dual Speaker Pairing	04
6.	Precautions for Use	0
7.	Troubleshooting	0

### What's in the Box

1.Trueno U300 Bluetooth Speaker: 1 Unit

2.USB A to Type C Cable: 1 Unit

3. Aux Cable: 1 Unit

5. Warranty Card: 1 Unit

6. Thank You Card: 1 Unit

#### Performance Index


Product Name	Trueno U300 Bluetooth Speaker
Audio Interface	Bluetooth, USB, Micro SD, AUX
Charging Interface	Туре С
Output Power	20W
Rated Voltage	11V
Bluetooth Version	V5.3+BR+EDR+BLE
Bluetooth Range	15 meters
Battery Type and Capacity	Lithium-ion, 4500mAh
Charging Time	4 hours
Playback Time	Up to 13 hours
IP Rating <sup>1</sup>	IPX6
Driver Size <sup>2</sup>	78mm*2
Frequency Range	20Hz-20KHz
Signal To Noise Ratio³	≥81dB
Impedance <sup>4</sup>	4 Ohms
Product Dimension	254*96.5*56.5mm
Product Weight	995g


The IP rating determines how resistant something is to environmental elements. Most IP numbers read IPXC each "X" being a placeholder for a number. The first number represents the level of resistance to dust/particles and the second representing its ability to withstand liquid.


Sound quality depends to a great extent on the size of the diaphragm, which is indicated by the driver diameter; the larger the diameter, the better the sound quality.

<sup>3.</sup> Signal to Noise Ratio is defined as the ratio of signal power to the noise power, it is represented in decibles. A Impedance refers to the load a peaker places on an amplifier Technically, impedance is the "resistance" a speaker offers to the current supplied by an amplifier because the output current of an amplifier is AC (not DC, like from a battery), this resistance is called impedance.

# Product Appearance And Structure







# Function Description

. and a Bescription				
Function	What to do			
	Long press: Power on/off the device			
$\circ$	Short press: Switch between Bluetooth, Aux, MicroSD card and USB input mode			
O	Double press: Enable dual speaker pairing mode (When in Bluetooth pairing mode)			
	Short press: Play/pause (While playing music)			
	Short press: Answer an incoming call			
7	Short press: End the ongoing call			
	Double press: Call latest incoming/ outgoing call			
	Short press: Decrease the volume			
<del>-</del>	Long press: Skip to previous track			
1	Short press: Increase the volume			
т	Long press: Skip to next track			

Indicator Light Status	Mode
Solid blue light	Power on/Music paused/Bluetooth device connected
Blue light off	Power off
Rapid flashing blue light	Pairing mode
Slow flashing blue light	Playing music/during call
Alternate red and blue light	Charging (When speaker is powered on)
No light	Low battery
Solid red light	Charging (When speaker is powered on/ off)
Solid green light*	Fully charged

<sup>\*</sup>While connected to charging cable

# How to Operate

Before Powering ON for the first time, please charge fully for good battery life.

# Charging

- Plug the small end of the Type C cable into the Type C connector port on the speaker.
- Plug the other end into a USB wall charger/computer/power bank that is powered on.

02 03

### Powering On

Long press the O button to power on/off the device.

## Pairing Via Bluetooth

Connecting any Bluetooth device

- When the speaker is turned on, it automatically enters bluetooth pairing mode.
- Open the Bluetooth settings on any Bluetooth device and search for device with name "Trueno U300" and connect.

#### Note

- "Trueno U300 Bluetooth Speaker" will automatically re-pair with the last paired device whenever it is within range.
- Devices with older Bluetooth versions may prompt you to input a passcode key. Please enter "0000" on your device and press OK to successfully connect with "Trueno U300 Bluetooth Speaker".

### MicroSD Card Operation

When a microSD card is inserted, the audio/music stored in the microSD card will automatically start playing.

#### Note:

- 1. Supports MP3 and WAV audio formats only.
- The speaker also has a memory function that will recall and continue from the last-played track whenever a microSD Card is reinserted into the speaker.

# **Aux Cable Operation**

Insert the 3.5mm AUX cable into the AUX input. "Trueno U300 Bluetooth Speaker" is ready to play audio/music through AUX mode.

### **USB Function**

When a USB Flash drive is inserted, the audio/music stored in the USB Flash drive will automatically start playing.

#### Note:

- Speaker is compatible with USB Flash Drives upto 64GB in size and supports MP3 and WAV audio formats only.
- The speaker also has a memory function that will recall and continue from the last-played track whenever a USB Flash drive is reinserted into the speaker.

# **Dual Speaker Pairing**

- 1. Power on both the Speakers.
- 2. While both the speakers are in Bluetooth pairing mode, double press the O button on 1 speaker to pair the speakers together.
- 3. Connect the speaker to a Bluetooth device. Now you can play music on both the speakers at the same time from a single Bluetooth device.
- 4. Power off any 1 speaker to disable dual speaker pairing mode.

#### Note:

Performance may vary based on a mobile device, distance, and environmental factors.

#### Precautions For Use

- Do NOT use at high volume for any extended period to avoid hearing damage.
- . Do NOT use while driving for phone calls or any other purpose.
- Do NOT use if there is any loud unusual noise. If this happens, please contact us at support@honeywellconnection.com.
- This product contains small parts which may be a choking hazard. Not suitable for children under the age of 3.
- This product contains magnetic material. Consult your physician before using the product in case you have a medical implant of any type.
- Do NOT attempt to disassemble this product as this may lead to a hazard and will void the warranty.
- Use this product only with the power supply provided along with this product (applicable for selected models only).
- Do NOT use this product near any form of excessive heat such as gas appliances and heating appliances.

### Troubleshooting

Problem	Solution			
No Power	Charge the battery.     Connect to the power source.			
Unsuccessful Bluetooth pairing	Restart the product and try pairing again.     Disable Bluetooth mode in your device and then re-enable it.			
Poor audio quality	Make sure the product is in the Bluetooth range.			
Low or no volume	• Increase the volume on "Trueno U300 Bluetooth Speaker" and/or connected device.			
Undiscoverable in Bluetooth pairing	The product may be paired to a different device, disconnect from the paired device. Trueno U300 Bluetooth Speaker" is not in Bluetooth mode, change to Bluetooth mode.			